




Loosen set screw, position arm, re-tighten set screw. Do not pull on arm.





2

