

BEAUBIEN 07








shipped as two sections. Carefully feed wires from section **A** up and through the cube of section **B**.


Tighten set screw when connector tube is fully inserted.



Insert removed arms into the cubes and secure set screws. The arms will be repositioned properly once the fixture has been installed to the ceiling.




Rotate arms shortest distance possible. Do not rotate 3/4 turn.




B


Insert arms then tighten set screw gently, but firmly.



В


* Screw gently, but firmly









After having marked anchor location on the ceiling, screw in ceiling anchors using appropriate screws





Loosen set screw and lower celing rod to allow mount to be screwed into the ceiling anchor





Raise ceiling stems into the anchored ceiling mount and tighten the set screw



Make connection











Rotate arms shortest distance possible. Do not rotate 3/4 turn.





Reposition arms into their proper final positions.
These arms were turned to facilitate shipping




Losen set screw, resposition arm then tighten set screw gently, but firmly.











Cubes may have shifted during shipping so assure that all cubes are straight and parallel with one another

Horizontal level is adjusted by tightening and losening the ceiling mount screws.


Be sure that screws are sufficiently secured for safety

Α





Vertical level is adjusted by moving the stem up and down between the two segmented lines





Insert bulbs and globes into the sockets

