



lambert&fils

1

To ensure efficient shipping, the fixture has been shipped partially dissasembled.

Begin by inserting removed arms (A,B) into the cubes and securing set screw.The arms will be repositioned properly once the fixture has been installed to the ceiling.






Insert arms then tighten set screw gently, but firmly.

$\underline{\land}$


Rotate arms shortest distance possible. Do not rotate 3/4 turn.






2X

After having marked anchor location on the ceiling, screw in ceiling anchors using appropriate screws





Loosen set screw and lower celing rod to allow mount to be screwed into the ceiling anchor




Raise ceiling stems into the anchored ceiling mount and tighten the set screw


6









Note that the ceiling rod is adjustable






Α

Horizontal level is adjusted by tightening and losening the ceiling mount screws. Be sure that screws are sufficiently secured for safety



 \triangle

Cubes may have shifted during shipping so assure that all cubes are straight and parallel with one another



В

Vertical level is adjusted by moving the stem up and down between the two segmented lines

